

THIXOTROPIC



ADDITIVE

For TAP Silicone RTV System
or TAP Platinum Silicone

- Changes silicone compound from flowable liquid to non-slumping paste
- Does not affect physical properties
- Easy to use

Net 8 fl oz

TAP Plastics Inc.

San Leandro CA 94577 • tapplastics.com

CAUTIONS:

In case of eye contact, flush at least 15 minutes with water. Obtain medical attention if irritation persists. Wash after skin contact. Obtain medical attention if irritation develops. Follow all instructions for safe use. **KEEP AWAY FROM CHILDREN.**

DIRECTIONS:

- Apply catalyzed but un-thickened silicone to model to form a 'skin coat' which will pick up detail.
- When skin coat gels, mix more silicone for a 'blanket coat'.
- Add .5% to 5% by weight of Thixotropic Additive to mixed silicone. Silicone will thicken within minutes.
- Apply a blanket coat at least 1/4" thick.
- Depending on model shape/size, silicone mold may require a rigid 'mother mold' for support.

MSDS for TAP Silicone Thixotropic Additive available at tapplastics.com

Date Code: 22213

Rev. 11/15/11